




PRESSURE WASHER
NV3100PWG
NV3400PWG
QUICK START GUIDE

2025 V01




Jackson, Wisconsin
Website: www.novuspowerequipment.com
Email: Support@novuspowerequipment.com
Toll-Free Phone: 800-409-7802

2025 V01

UNPACKING

Carefully remove the Pressure Washer out from the carton/box and place the unit on the ground or other solid surface. Do not discard the packaging until you have confirmed the following items are present.



1. Main Unit	8. Operators Manual & Quick Start Guide
2. Upper Handle	9. Tools – Wrench 10/8mm, Screwdriver
3. High Pressure Hose	10. Wire Hanger – High Pressure Hose
4. Spray Gun	11. 2 x M6 Bolts, Washers
5. Nozzle Cleaning Tool	12. Holder – Spray Gun
6. Spray Wand	13. Oil Bottle 20 fl oz (0.6L)
7. Spray Nozzles (5 pcs) 0°, 15°, 25°, 40°, Soap	14. Oil Funnel with tube



READ AND UNDERSTAND THE OPERATOR'S MANUAL AND ALL SAFETY WARNINGS BEFORE USE

Quick Start Guide Contents

- Unpacking / Package Contents
- Assembly Instructions
- Starting and Operating Procedures

If you require assistance during setup or operation of your new tiller, please contact our customer support team toll-free at (800) 409-7802 or email at support@novuspowerequipment.com

Please contact our customer support team at 1-800-409-7802 if any of the above loose parts are missing from the carton.

ASSEMBLY

Your Pressure Washer requires limited assembly prior to use. If you have any questions regarding the assembly of this product, call our Technical Support Team at 1-800-409-7802 M-F 8am-4pm CST or by email at support@novuspowerequipment.com Please have your model and serial number available at the time of the call.

Install the Upper Handle

Align the two ends of the upper handle (A) with the two upright tubes of the engine base (B), and then press down firmly until positioning pins pop into place on both sides. Fig 1

1

Install the high-pressure hose hook and spray gun hook

a. As shown in Figure 2, squeeze the high-pressure pipe hook (A) in the middle and hang it in the hole of the panel.

b. As shown in Figure 3, install the spray gun holder (C) on the right side of the upper handle frame with 2 M6x50 bolts (A) 2 washers (B).

2




Fig 1




Fig 2




Fig 3

3

Spray Nozzles

Press the spray nozzles into their corresponding color matched openings on the pressure washer's top panel. See fig 4

(A) Red = 0°, (B) Orange = 15°, (C) Green = 25°, (D) White = 40°, (E) Black = Soap




Fig 4

4

Assemble spray gun and high-pressure hose.

a. Attach the spray wand onto the gun by rotating the coupler nut clockwise until hand tight. Do not overtighten. Figure 5

b. Connect one end of the high-pressure hose to the threaded joint of the spray gun by Rotating the collar nut of the high-pressure hose clockwise until it is hand tight. Figure 6




Fig 5




Fig 6

- c. Uncoil and straighten the high-pressure hose to prevent kinks.
- d. Connect the open end of the high-pressure hose to the outlet of the pump by rotating the collar nut clockwise until it is hand tight. Fig 7.




Fig 7

Connect the Garden Hose.

With the water turned off, connect the garden hose to the water inlet by turning the coupler clockwise and tighten by hand. Fig 8





Fig 8

6

Add Engine Oil

1. Place the unit on a flat, level surface.



2. Remove the oil dipstick by turning counterclockwise

3. Using a funnel, add up to 20.3 fl. oz. (0.6 L) of oil to the engine. The oil should be near the top thread of the filler neck.

4. Check the oil level using the dipstick. DO NOT screw in when checking.


5. When finished screw in the dipstick securely.

7

Add Fuel

1. Slowly add fresh, regular unleaded gasoline containing 10% or less ethanol to the tank until it reaches the Red fuel level indicator of the fuel screen. DO NOT overfill. A minimum of ¼ in. (6.4 mm) of space left in the tank is required for gasoline expansion. Fig 9

Fig 9



2. Replace and tighten the fuel tank cap.

3. Immediately wipe up any spills.

Connect Spray Nozzle

1. Engage the trigger safety lock on the spray gun.

2. Select a spray nozzle according to your cleaning needs. Fig 10

3. Pull back on the spray wand quick connect collar and insert the desired spray tip and release the collar. Tug on the spray tip to ensure it is firmly secure. Fig 11




Fig 10




Fig 11

Congratulations, your machine is now ready to operate. Please read the entire operator's manual for full safety and operations guidelines.

Starting and Operating Procedures

This section of the quick start guide provides the basic instructions on how to start and operate your new water pump. This quick start guide is not a comprehensive guide, we recommend the operator's manual is read and understood before using your new equipment.

!!! IMPORTANT INFORMATION

Prior to attempting to start the engine the water supply must be connected to the pump and turned on.


STARTING THE ENGINE

1. Check oil level and add oil if necessary

2. Add fresh, unleaded 87 octane gasoline containing less than 10% ethanol to the fuel tank.


3. Turn engine shut-off switch clockwise to the "ON" position.

IGNITION SWITCH




4. Slide Choke lever on engine fully to the Left (Full Choke position)

CHOKE LEVER




5. Move the Fuel Shut-Off lever fully to the Right (Open position)

FUEL VALVE




6. Start the engine by pulling the recoil starter handle slowly until resistance is felt, then pull rapidly.



7. Once the engine starts, slowly slide the choke lever to the Right into the Off-choke position.

Once the engine is started firmly grasp the spray gun with both hands. Point the spray gun in a safe direction, disengage the spray gun trigger lock by pressing down until it clicks into the back of the trigger.

Pressure Washing



a. Depress the spray gun trigger to begin spraying.

b. Release the trigger to stop spraying.

